




















Position of Parts in Engine Compartment <LHD 2AR-FE>



















- A 1 Low Pitched Horn Assembly
- A 2 Hood Courtesy Switch (Hood Lock Assembly)
- A 3 Ambient Temperature Sensor (Thermistor Assembly)
- A 4 High Pitched Horn Assembly
- A 5 Fog Light Assembly LH
- A 6 Exhaust Gas Sensor
- A 7 Cooling Fan Motor
- A 8 No. 2 Cooling Fan Motor
- A 12 Front Airbag Sensor LH
- A 15 Wireless Door Lock Buzzer
- A 16 Front Speed Sensor LH
- A 17 Headlight Assembly LH
- A 18 Headlight Assembly LH
- A 19 Headlight Assembly LH
- A 20 Headlight Assembly LH
- A 21 Headlight Assembly LH
- A 25 Windshield Wiper Motor Assembly
- A 27 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 37 Security Horn Assembly
- A 40 Brake Actuator Assembly
- A 42 Headlight Cleaner Washer Motor and Pump Assembly
- A 43 Headlight Cleaner Control Relay
- A 44 Front Speed Sensor RH
- A 45 Windshield Washer Motor and Pump Assembly
- A 46 Level Warning Switch Assembly
- A 47 Pressure Sensor (A/C Tube & Accessory Assembly)
- A 48 Fog Light Assembly RH
- A 49 Front Airbag Sensor RH
- A 50 Headlight Assembly RH
- A 51 Headlight Assembly RH
- A 52 Headlight Assembly RH
- A 53 Headlight Assembly RH
- A 54 Headlight Assembly RH
- A 56 Front Tire Pressure Monitor Initiator
- A 59 Junction Connector
- A 60 Front Wiper Deicer (Windshield Glass)
- A 63 Junction Connector
- A 64 ECM
- A 65 Ambient Temperature Sensor (Thermistor Assembly)
- A 66 Headlight Assembly LH
- A 67 Headlight Assembly LH
- A 68 Headlight Assembly LH
- A 69 Brake Actuator Assembly
- A 70 Headlight Assembly RH
- A 71 Headlight Assembly RH
- A 72 Headlight Assembly RH
- A 74 Millimeter Wave Radar Sensor Assembly


Position of Parts in Engine Compartment <LHD 2AR-FE>




Position of Parts in Engine Compartment <LHD 2AR-FE>



Position of Parts in Engine Compartment <LHD 2AR-FE>





(Front Side Marker Light and Front Turn Signal Light)




(Clearance Light, DRL and Low LED Type)



(Headlight Leveling Motor and High)



(Front Side Marker Light and Front Turn Signal Light)



(Clearance Light, DRL and Low LED Type)



(Headlight Leveling Motor and High)

