


Position of Parts in Instrument Panel <LHD>



H 189 Back Sonar or Clearance Sonar Switch Assembly
H 190 Auto High Beam Switch
H 191 Engine Stop and Start ECU Assembly
H 192 Shift Position Indicator
H 193 Network Gateway ECU
H 194 Driving Support ECU Assembly
H 195 Multi-Media Module Receiver Assembly or Radio Receiver Assembly
H 196 Multi-Media Module Display
H 197 Junction Connector
H 198 Junction Connector
H 199 Junction Connector
H 200 Junction Connector
H 202 Junction Connector
H 203 Junction Connector
H 204 Junction Connector
H 205 Junction Connector
H 206 Junction Connector
H 207 Horn Relay
H 210 Combination Meter Assembly
H 212 Spiral Cable Sub-Assembly
H 213 Junction Connector
H 215 Back Sonar or Clearance Sonar Switch Assembly

Position of Parts in Instrument Panel <LHD>

