


Position of Parts in Instrument Panel <LHD>




H 191	Back Sonar or Clearance Sonar Switch Assembly
H 192	Auto High Beam Switch
H 193	Shift Position Indicator
H 194	Certification ECU
H 195	Network Gateway ECU
H 196	Driving Support ECU Assembly
H 197	Junction Connector
H 198	Junction Connector
H 199	Junction Connector
H 201	Junction Connector
H 202	Junction Connector
H 203	Junction Connector
H 204	Junction Connector
H 205	Junction Connector
H 208	Junction Connector
H 209	Combination Meter Assembly
H 210	Junction Connector
H 211	Hybrid Vehicle Control ECU
H 212	Hybrid Vehicle Control ECU
H 213	Spiral Cable Sub-Assembly
H 214	Junction Connector
H 215	Back Sonar or Clearance Sonar Switch Assembly
H 216	Vehicle Approaching Speaker Controller
H 217	Vehicle Approaching Speaker Switch

Position of Parts in Instrument Panel <LHD>


H191

Black




H192

Gray




H193

White




H194

White




H195

Black




H196

White




H197

White




H198

Black




H199

White




H201

White




H202

White




H203

White




H204

White




H205

White



H208

White




H209

Sky Blue




H210

White




H211

Gray




H212

Gray




H213

Black




Position of Parts in Instrument Panel <LHD>


H214
White



H215
White



H216
White



H217
Black

