


Position of Parts in Body (LHD/2GR-FKS, 6AR-FSE, A25A-FKS)



- K 1 Seat Memory Switch RH
- K 2 Front Door Illumination Light RH (Front Door Trim Board Sub-Assembly RH)
- K 3 Front Door Inside Handle Illumination Light Assembly RH (Front Door Trim Board Sub-Assembly RH)
- K 4 Seat Memory Switch LH
- K 5 Front Door Illumination Light LH (Front Door Trim Board Sub-Assembly LH)
- K 6 Front Door Inside Handle Illumination Light Assembly LH (Front Door Trim Board Sub-Assembly LH)
- L 1 Rear Power Window Regulator Switch Assembly (for RH Door)
- L 2 Courtesy Light Assembly (for Rear RH Side)
- L 3 Rear Door Lock with Motor Assembly RH
- L 4 Power Window Regulator Motor Assembly RH (for Rear Door)
- L 5 Electrical Key Antenna (Rear Door Outside Handle Assembly RH)
- L 6 Rear Speaker Assembly LH
- L 7 Rear Power Window Regulator Switch Assembly (for LH Door)
- L 8 Courtesy Light Assembly (for Rear LH Side)
- L 9 Rear Door Lock with Motor Assembly LH
- L 10 Power Window Regulator Motor Assembly LH (for Rear Door)
- L 11 Electrical Key Antenna (Rear Door Outside Handle Assembly LH)
- L 12 Rear Door Lock with Motor Assembly RH
- L 13 Rear Door Lock with Motor Assembly LH
- M 1 Rear Speaker Assembly RH
- M 2 Rear Door Illumination Light RH (Rear Door Trim Board Sub-Assembly RH)
- M 3 Rear Door Inside Handle Illumination Light Assembly RH (Rear Door Trim Board Sub-Assembly RH)
- M 4 Rear Speaker Assembly LH
- M 5 Rear Door Illumination Light LH (Rear Door Trim Board Sub-Assembly LH)
- M 6 Rear Door Inside Handle Illumination Light Assembly LH (Rear Door Trim Board Sub-Assembly LH)

