

Ground Points in Engine Compartment (RHD/A25A-FXS)

