



Position of Parts in Seat (LHD/Front Seat)




- N 53 Front Seat Airbag Assembly RH
- N 54 Front Seat Airbag Assembly LH
- N 67 Front Seat Inner Belt Assembly LH
- N 68 Front Seat Inner Belt Assembly RH
- U 61 Seat Position Air Bag Sensor
- V 3 Seat Back Climate Control Blower RH
- V 5 Reclining Motor (Front Seatback Frame Sub-Assembly RH)
- V 7 Lumbar Support Adjuster Assembly RH (for Front Seat)
- V 8 Lumbar Support Adjuster Assembly RH (for Front Seat)
- V 9 Lumbar Support Adjuster Assembly RH (for Front Seat)
- V 10 Front Power Seat Switch Assembly RH
- V 14 Seat Back Climate Control Blower LH
- V 18 Reclining Motor (Front Seatback Frame Sub-Assembly LH)
- V 20 Lumbar Support Adjuster Assembly LH (for Front Seat)
- V 21 Lumbar Support Adjuster Assembly LH (for Front Seat)
- V 22 Lumbar Support Adjuster Assembly LH (for Front Seat)
- z 22 Front Seat Inner Belt Assembly RH, Belt Warning Occupant Detection Sensor (for Passenger Seat)

Position of Parts in Seat (LHD/Front Seat)




90980-12698




90980-12698




90980-10942




90980-12520




90980-12416




90980-12733




90980-12335




90980-12341




90980-12341




90980-12341




90980-12366




90980-12733




90980-12335




90980-12341



90980-12341



90980-12341



90980-11987