



Position of Parts in Instrument Panel (LHD/2GR-FKS, 6AR-FSE, A25A-FKS)




- I 1 Radio Receiver Assembly
- I 2 Navigation ECU
- I 4 Radio Receiver Assembly
- I 5 Radio Receiver Assembly
- N 9 Certification ECU (Smart Key ECU Assembly)
- N 33 Airbag ECU Assembly
- N 34 Airbag ECU Assembly
- N 41 Clearance Warning ECU Assembly
- N 91 Acceleration Sensor Assembly RH
- N 92 No. 20 Junction Connector
- N 93 No. 21 Junction Connector
- N 94 No. 22 Junction Connector
- N 97 No. 1 Junction Connector
- N102 No. 25 Junction Connector
- N103 No. 26 Junction Connector
- N104 No. 27 Junction Connector
- N106 No. 2 CAN Junction Terminal
- z 1 Air Conditioning Amplifier Assembly, Air Conditioning Harness Assembly
- z 4 Steering Pad Switch Assembly, Spiral Cable Sub-Assembly
- z 5 No. 1 Switch Wire, Spiral Cable Sub-Assembly
- z 6 Spiral Cable Sub-Assembly, Steering Vibration ECU
- z 7 Spiral Cable Sub-Assembly, Horn Button Assembly
- z 8 Spiral Cable Sub-Assembly, Horn Button Assembly
- z 10 Headlight Dimmer Switch Assembly, Steering Sensor
- z 11 Headlight Dimmer Switch Assembly, Windshield Wiper Switch Assembly


Position of Parts in Instrument Panel (LHD/2GR-FKS, 6AR-FSE, A25A-FKS)




90980-12C89




90980-12C91




90980-12C85




90980-12C87




90980-12B77




90980-12C55




90980-12C54



90980-12924




90980-10845




90980-12372


N93
White



N94
Blue



N97
White



N102
Blue

