



Position of Parts in Instrument Panel (LHD/A25A-FXS)



G 36	Multiplex Network Body ECU
G 37	Multiplex Network Body ECU
G 38	Multiplex Network Body ECU
G 39	Air Conditioning Amplifier Assembly
G 40	Air Conditioning Amplifier Assembly
G 41	Air Conditioning Amplifier Assembly
G 42	Vehicle Approaching Speaker Controller
G 44	Clock Assembly
G 45	No. 3 Combination Switch Assembly
G 46	Double Lock Door Control Relay Assembly
G 47	Certification ECU (Smart Key ECU Assembly)
G 49	Push Start Switch
G 50	No. 1 Indoor Electrical Key Antenna Assembly (Front Floor)
G 51	Steering Lock Actuator or Upper Bracket Assembly
G 52	ID Code Box (Immobiliser Code ECU)
G 53	No. 1 Power Outlet Socket Assembly
G 55	Cooler Thermistor (Room Temperature Sensor)
G 56	Remote Operation Controller Assembly
G 57	Data Link Connector 3
G 59	Hybrid Vehicle Control ECU
G 60	Hybrid Vehicle Control ECU
G 61	Luggage Door Opening Cancel Switch Assembly
G 62	Steering Sensor
G 63	Multiplex Tilt and Telescopic ECU
G 64	Airbag ECU Assembly
G 65	No.1 Clearance Warning Buzzer
G 66	Network Gateway ECU
G 67	Shift Position Indicator
G 68	Airbag Cut Off Switch Cylinder Sub-Assembly
G 70	Driver Side Knee Airbag Squib (Lower No. 1 Instrument Panel Airbag Assembly)
G 71	Front Passenger Side Knee Airbag Squib (Lower No. 2 Instrument Panel Airbag Assembly)
G 72	Front Footwell Light (No. 1 Interior Illumination Light Assembly RH)
G 73	Front Footwell Light (No. 1 Interior Illumination Light Assembly LH)
G 74	Glove Box Light Assembly
G 75	Steering Column Assembly
G 76	Steering Column Assembly


Position of Parts in Instrument Panel (LHD/A25A-FXS)

G36
Black




90980-12C63

G37
Black




90980-12C62

G38
Black




90980-12C61

G39
White




90980-12760

G40
Black




90980-12761

G41
Gray




82824-52380

G42
White




90980-12558

G44
White




90980-12558

G45
Black




90980-12C74

G46
White



90980-12812

G47
White




90980-12B78

G49
Black




90980-12368


Position of Parts in Instrument Panel (LHD/A25A-FXS)



90980-12795




90980-12092




90980-12366




90980-12498




90980-12128




90980-12361




90980-12D97




90980-12429




90980-12431




90980-10906




90980-12368




90980-12976



90980-12C56



90980-10825



90980-12912

Position of Parts in Instrument Panel (LHD/A25A-FXS)

