


① : Engine Room R/B Assembly No. 1

○ : Engine Room J/B Assembly No. 1



Front Fender Apron RH

(LHD)

- * 1:80A RH J/B ALT
- * 2:100A P/I ALT
- * 3:150A ALT
- * 4:80A P/I-B NO.2
- * 5:40A EPB
- * 6:40A VVT
- * 7:40A LH J/B-B
- * 8:50A FAN NO.3
- * 9:50A LUG-J/B ALT
- * 10:30A ABS NO.1
- * 11:50A HTR
- * 12:80A EPS
- * 13:30A TVD
- * 14:30A H-LP CLN
- * 15:50A FAN NO.2
- * 16:60A LH J/B ALT
- * 17:30A P/I-B NO.1
- * 18:40A RH J/B-B
- * 19:30A F/PMP
- * 20:30A ST
- * 21:50A ABS NO.2



Unit A




① : Engine Room R/B Assembly No. 1

○ : Engine Room J/B Assembly No. 1


Front Fender Apron LH

(RHD)



Unit A

Top View



Side View

