



Position of Parts in Instrument Panel (LHD)

* 4: Before Sep. 2017 Production
 * 5: From Sep. 2017 Production




K1	Skid Control Buzzer
K2	Luggage Compartment Door Opening Switch Assembly
K3	No. 2 Instrument Panel Register Assembly
K4	Driving Support ECU Assembly
K5	Integration Control & Panel Assembly
K6	Head Up Display Switch Assembly
K7	Trip Switch
K9	Clearance Warning ECU Assembly
K10	Main Body ECU
K11	Main Body ECU
K12	Main Body ECU
K13	Lower No. 1 Instrument Panel Airbag Assembly
K14	Front Foot Light LH (No. 1 Interior Illumination Light Assembly LH)
K15	Option Connector (Remote Engine Starter)
K16	DLC3
K17	Front No. 2 Speaker Assembly LH
K18	Multiplex Tilt & Telescopic ECU
K19	Electric Parking Brake Switch Assembly
K20	Steering Lock Actuator Assembly
K21	Tilt Steering Gear Assembly with Motor
K22	Tilt & Telescopic Switch
K23	Headlight Dimmer Switch Assembly
K24	Combination Switch Assembly
K25	Spiral Cable Sub-Assembly
K26	Spiral Cable Sub-Assembly
K27	Spiral Cable Sub-Assembly
K28	Steering Sensor
K29	Windshield Wiper Switch Assembly
K30	Windshield Wiper Switch Assembly
K31	Tilt Steering Gear Assembly with Motor
K128	Spiral Cable Sub-Assembly


Position of Parts in Instrument Panel (LHD)




90980-10860




90980-12366




90980-12366




90980-12422




90980-12553




82824-33470




90980-12551




90980-12924



82824-33350



90980-12909



90980-12908

Position of Parts in Instrument Panel (LHD)

