



Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

d1	Instrument Panel Passenger Airbag without Door Assembly
d2	Instrument Panel Passenger Airbag without Door Assembly
o1	Console Box Illumination Light Assembly
p1	No. 1 Switch Wire
p2	Spiral Cable Sub-Assembly
r1	Radio Receiver Assembly
r2	Radio Receiver Assembly
r3	Extension Module
s1	Radio Receiver Assembly
s2	Multi-Display
s3	Accessory Meter Assembly
z1	A/C Amplifier Assembly , Air Conditioner Harness Assembly
z2	Spiral Cable Sub-Assembly , Driver Side Squib Circuit (Horn Button Assembly)
z3	Spiral Cable Sub-Assembly , Driver Side Squib Circuit (Horn Button Assembly)
z4	Spiral Cable Sub-Assembly , Steering Pad Switch Assembly
z5	Spiral Cable Sub-Assembly , Steering Wheel Heater Control Assembly
z6	Spiral Cable Sub-Assembly , Cruise Control Switch Wire
z7	Steering Pad Switch Assembly , No. 1 Switch Wire
z12	Spiral Cable Sub-Assembly , Steering Wheel Assembly
z13	Spiral Cable Sub-Assembly , Steering Wheel Heater Control Assembly
z14	Spiral Cable Sub-Assembly , No. 1 Switch Wire
z15	Steering Pad Switch Assembly , Cruise Control Main Switch

Position of Parts in Instrument Panel (LHD)



90980-12219



90980-12224

