



Position of Parts in Instrument Panel <LHD>




N 123 Junction Connector
N 125 Junction Connector
N 126 Junction Connector
N 128 Junction Connector
N 130 Junction Connector
N 131 Junction Connector
N 132 Junction Connector
N 133 Junction Connector
N 134 Junction Connector
N 178 Junction Connector
N 179 Junction Connector
N 180 Junction Connector
N 181 Junction Connector
N 187 Junction Connector
N 188 Junction Connector
N 189 Junction Connector
N 190 Junction Connector
N 191 Junction Connector
N 192 Junction Connector
N 193 Junction Connector
N 194 Junction Connector
N 195 Junction Connector
N 196 Junction Connector
N 197 Junction Connector
N 198 Junction Connector

Position of Parts in Instrument Panel <LHD>


N123
Blue




N125
Blue




N126
Blue




N128
Blue




N130
Black




N131
Gray




N132
Black




N133
Black




N134
Black




N178
Gray




N179
Blue




N180
Gray




N181
Gray




N187
Black




N188
Black




N189
Black



N190
Black




N191
Black




Position of Parts in Instrument Panel <LHD>


N192
Black




N193
Black




N194
Black




N195
Black



N196
Black



N197
Black



N198
Black

