



Position of Parts in Instrument Panel <RHD>




N 123 Junction Connector
N 124 Junction Connector
N 126 Junction Connector
N 127 Junction Connector
N 130 Junction Connector
N 131 Junction Connector
N 132 Junction Connector
N 133 Junction Connector
N 134 Junction Connector
N 165 Junction Connector
N 167 Junction Connector
N 177 Junction Connector
N 178 Junction Connector
N 181 Junction Connector
N 182 Junction Connector
N 183 Junction Connector
N 191 Junction Connector
N 192 Junction Connector
N 193 Junction Connector
N 195 Junction Connector
N 196 Junction Connector
N 197 Junction Connector
N 198 Junction Connector
N 199 Junction Connector
N 200 Junction Connector
N 201 Junction Connector
N 202 Junction Connector

Position of Parts in Instrument Panel <RHD>


N123
Blue




N124
White




N126
Blue




N127
Blue




N130
Black




N131
Gray




N132
Black




N133
Black




N134
Black




N165
Black




N167
Blue




N177
Gray




N178
Gray




N181
Black




N182
Black




N183
Blue



N191
Black




N192
Black




Position of Parts in Instrument Panel <RHD>


N193
Black




N195
Black




N196
Black




N197
Black




N198
Black




N199
Black



N200
Black



N201
Black



N202
Black

