


ENGINE (2JZ-GE)

HOW TO PROCEED WITH TROUBLESHOOTING


DI63H-06

When using hand-held tester, troubleshoot in accordance with the procedure on the following page.



*: See Pub. No. RM588E on page DI-24.

When not using hand-held tester, troubleshoot in accordance with the procedure on the following page.



*: See Pub. No. RM588E on page DI-24