


AUTOMATIC TRANSMISSION (2JZ-GE)

HOW TO PROCEED WITH TROUBLESHOOTING

DI61K-03

When using hand-held tester, troubleshoot in accordance with the procedure on the following pages.



When not using hand-held tester, troubleshoot in accordance with the procedure on the following pages.

