



Audio System, Multi Display, LEXUS Navigation System and
Parking Assist (Rear View Monitor or Back Guide Monitor)

Audio System, Multi Display, LEXUS Navigation System and
Parking Assist (Rear View Monitor or Back Guide Monitor)

Wiring diagram for the Multi-Media Module Navigation Assembly. The diagram shows the module's pin connections to various vehicle components.

Multi-Media Module Navigation Assembly Pins:

- 6 (GND)
- 10 (IVI-)
- 11 (IVI+)
- 12 (CMP-)
- 13 (CMP+)
- 15 (REV)
- 16 (SPD)
- 7 (ADET)
- 1 (GVIF)
- 3 (MSLD)
- 4 (MIC-)
- 5 (MIC+)
- 1 (TX-)
- 2 (TX+)
- 8 (+B)

Vehicle Components and Connections:

- IG (10A ECU-IG RH):** Connected to Pin 6 (GND).
- SH (3) and SB (3):** Connected to Pin 10 (IVI-) and Pin 11 (IVI+) via a 4-pin connector.
- Y (Parking Brake SW):** Connected to Pin 12 (CMP-).
- V (Combination Meter):** Connected to Pin 13 (CMP+).
- BR (DLC3):** Connected to Pin 15 (REV).
- LW1 (Body ECU):** Connected to Pin 16 (SPD).
- TC:** Connected to Pin 7 (ADET).
- GVIF (1):** Connected to Pin 1 (GVIF) via a 4-pin connector.
- L (Shielded) and R (Shielded):** Connected to Pin 3 (MSLD) and Pin 4 (MIC-) via a 4-pin connector.
- W-B:** Connected to Pin 5 (MIC+).
- W-R:** Connected to Pin 1 (TX-).
- R:** Connected to Pin 2 (TX+).
- GR (GPS Antenna):** Connected to Pin 8 (+B).

Legend:

- * 4 : w/ Parking Assist (Back Guide Monitor)
- * 6 : w/ Parking Assist (Rear View Monitor)

B
(*4) — (A)

13

14

15

16

