


* 3: Before Sep. 2007 Production

* 4: From Sep. 2007 Production



- b 1 Ultrasonic Sensor (Rear Corner LH)
- b 2 Ultrasonic Sensor (Rear Center LH)
- b 3 Ultrasonic Sensor (Rear Center RH)
- b 4 Ultrasonic Sensor (Rear Corner RH)

- e 2 Rear Stabilizer Control ECU
- e 3 Converter (Active Stabilizer)
- e 4 Converter (Active Stabilizer)
- e 5 Converter (Active Stabilizer)
- e 6 Converter (Active Stabilizer)

- o 1 Speed Sensor (Rear LH)
- o 2 Height Control Sensor (Rear)

- p 1 Speed Sensor (Rear RH)

- q 1 Door Outside Handle (Front LH)
- q 2 Electrical Key Oscillator (Front Door LH)

- r 1 Door Outside Handle (Front RH)
- r 2 Electrical Key Oscillator (Front Door RH)

- s 1 Door Outside Handle (Rear LH)
- s 2 Electrical Key Oscillator (Rear Door LH)

- t 1 Door Outside Handle (Rear RH)
- t 2 Electrical Key Oscillator (Rear Door RH)

- w 1 Stereo Component Amplifier

- z 5 Door ECU (Front LH) , Outer Rear View Mirror (LH)
- z 6 Door ECU (Front RH) , Outer Rear View Mirror (RH)
- z 11 Rear Stabilizer Control ECU , Rear Stabilizer Control Actuator Assembly
- z 15 Rear Stabilizer Control ECU , Rear Stabilizer Control Actuator Assembly
- z 16 Rear Stabilizer Control ECU , Rear Stabilizer Control Actuator Assembly

