











* 1:1UR-FSE, 1UR-FE, 3UZ-FE
 * 2:3GR-FSE, 3GR-FE, 2GR-FSE

- A 33 Parking Brake SW
- A 34 Junction Connector
- A 35 Junction Connector
- A 36 Accelerator Position Sensor
- A 37 Stop Lamp SW
- A 38 Brake Pedal Stroke Sensor
- A 39 Absorber Control ECU
- A 40 Clearance Warning ECU
- A 41 Body ECU (Cowl Side J/B RH)
- A 42 Steering Control ECU
- A 43 Kick Down SW
- A 49 Brake Pedal Load Sensing SW
- A 50 Blower Motor
- A 55 Headlamp Swivel ECU
- A 56 Headlamp Swivel ECU
- A 57 Body ECU (Cowl Side J/B LH)
- A 62 Skid Control ECU
- A 63 Skid Control ECU

Position of Parts in Instrument Panel <LHD From Jul. 2006 Production>



(Before Sep. 2007 Production)



(From Sep. 2007 Production)

