


* 5:From Sep. 2009 Production



- L 122 Yaw Rate Sensor
- L 123 Display & Navigation Module Display
- L 124 Pre-Crash System Cancel Switch Assembly
- L 125 Display & Navigation Module Display
- L 126 Radio Receiver Assembly
- L 127 Junction Connector
- L 128 Telematics Transceiver
- L 129 Display & Navigation Module Display
- L 130 Display & Navigation Module Display
- L 131 Display & Navigation Module Display
- L 135 Display & Navigation Module Display
- L 136 IEEE Connector
- L 137 Junction Connector
- L 138 Display & Navigation Module Display
- L 139 Display & Navigation Module Display

Position of Parts in Instrument Panel <LHD From Jul. 2006 Production>

