





V 3 Side Airbag Squib (Front RH)
V 39 Front Seat Inner Belt (RH)

W 4 Front Seat Inner Belt (LH)
W 5 Side Airbag Squib (Front LH)


c 1 Power Seat Motor (Front RH Seat Slide Control)
c 2 Seat Heater (Front RH)
c 3 Front Seat Inner Belt (RH)
c 4 Power Seat Motor (Front RH Seat Front Vertical Control)
c 5 Junction Connector
c 6 Position Control ECU and SW (Front RH Seat)
c 7 Position Control ECU and SW (Front RH Seat)
c 8 Power Seat SW (Front RH Seat Lumbar Support)
c 9 Junction Connector
c 10 Power Seat Motor (Front RH Seat Rear Vertical Control)
c 11 Seat Climate Control Blower (Front RH Seat Cushion)
c 12 Foot Lamp (Rear RH)
c 13 Power Seat Motor (Front RH Seat Lumbar Support)
c 14 Seat Climate Control Blower (Front RH Seat Back)
c 15 Power Seat Motor (Front RH Seat Reclining Control)
c 16 Power Seat SW (Front RH Seat)

d 1 Front Seat Inner Belt (LH)
d 2 Seat Heater (Front LH)
d 3 Power Seat Motor (Front LH Seat Slide Control)
d 4 Power Seat Motor (Front LH Seat Front Vertical Control)
d 5 Junction Connector
d 6 Power Seat SW (Front LH Seat Lumbar Support)
d 7 Position Control ECU and SW (Front LH Seat)
d 8 Position Control ECU and SW (Front LH Seat)
d 9 Junction Connector
d 10 Power Seat Motor (Front LH Seat Rear Vertical Control)
d 11 Seat Climate Control Blower (Front LH Seat Cushion)
d 12 Foot Lamp (Rear LH)
d 13 Power Seat Motor (Front LH Seat Lumbar Support)
d 14 Seat Climate Control Blower (Front LH Seat Back)
d 15 Power Seat Motor (Front LH Seat Reclining Control)
d 16 Power Seat SW (Front LH Seat)


Position of Parts in Seat <LHD Before Jul. 2006 Production>





Position of Parts in Seat <LHD Before Jul. 2006 Production>




(Before Sep. 2008 Production)



(From Sep. 2008 Production)



(Before Sep. 2008 Production)



(From Sep. 2008 Production)

