
























- A 1 Airbag Sensor (Front LH)
- A 2 Windshield Washer Motor
- A 3 Headlamp Cleaner Motor
- A 4 Water Level Warning SW
- A 5 Headlamp Cleaner Control Relay
- A 6 Engine ECU
- A 7 Engine ECU
- A 8 Junction Connector
- A 9 Junction Connector
- A 10 Junction Connector
- A 11 Junction Connector
- A 12 Absorber Control Actuator (Front LH)
- A 13 Skid Control ECU
- A 14 Skid Control ECU
- A 15 Skid Control ECU
- A 16 Brake Actuator
- A 17 Junction Connector
- A 18 Wireless Door Lock Buzzer
- A 19 Turn Signal Lamp (Front Side LH)
- A 20 Windshield Wiper Motor (RHD)
- A 21 Height Control Sensor (Front)
- A 22 Brake Stroke Simulator Cylinder
- A 23 Brake Fluid Level Warning SW
- A 24 Power Steering ECU
- A 25 Fuel Pump Resistor (3UZ-FE)
- A 26 Airbag Sensor (Front RH)
- A 27 Absorber Control Actuator (Front RH)
- A 28 Security Horn
- A 29 Turn Signal Lamp (Front Side RH)
- A 44 Short Connector (Brake Stroke Simulator Cylinder)
- A 45 Short Connector (Brake Stroke Simulator Cylinder)
- A 51 A/C Pressure Sensor (Low)

- B 1 Fog Lamp (Front RH)
- B 2 Headlamp Assembly (RH)
- B 3 Cooling Fan ECU
- B 4 A/C Pressure Sensor
- B 5 Ambient Temp. Sensor
- B 6 Horn (High)
- B 7 Engine Hood Courtesy SW
- B 8 Millimeter Wave Radar Sensor
- B 9 Horn (Low)
- B 10 Smog Ventilation Sensor
- B 11 Headlamp Assembly (LH)
- B 12 Fog Lamp (Front LH)

Position of Parts in Engine Compartment <RHD 3UZ-FE>



Position of Parts in Engine Compartment <RHD 3UZ-FE>

