



Light Control Sensor

- This sensor contains a scanner portion (integrated photosensor) that detects the brightness of the area surrounding the vehicle and outputs it in the form of a frequency signal to the MPX body ECU. This sensor is located in the center of the front defroster above the instrument panel.



Light Control Sensor Cross Section

A4270108E