


Multi Display DVD Mode Function

DVD Mode Screen

- When the "audio" switch on the panel switch is pressed while a DVD video or a video CD is being played, the screen transfers to the DVD mode screen, where the operating conditions of the DVD video or video CD, as well as the operating screen, can be displayed.
- When a DVD video that supports 5.1 channel multi surround is being played, the "Mark Levinson Premium Sound System" reproduces in-your-face sound quality.




A4270060E

Multi Display Audio Mode Functions

Audio Mode Screen

- When the "audio" switch on the panel switch is pressed while the audio system is being used, the screen transfers to the audio mode screen, where various types of audio adjustments can be made. This includes the displaying of the operating conditions of the music sources (AM/FM radio, Cassette, CD, etc.), operating them, and adjusting sound quality, sound volume, and balance.



A4270052E