


Fuel Lid Opener

- An "electric fuel lid opener" is used and provided on all models as standard equipment.


Fuel Lid Opener System Components

- Press the fuel lid opener switch in the integration switch mounted on the left side of the instrument panel in order to open the fuel lid.



A4270245B

Fuel Lid Opener System Operation



A4270246B