


Skid Control ECU

- The skid control ECU processes the signals received from the sensors and effects brake control for the ABS, TRC, VSC, and brake assist. Also, it maintains communication with the engine ECU by outputting control signals.



* Appears on the multi-information display.