

## Idle Speed Control

- Controls the fast idle speed in accordance with the engine coolant temperature, and the idle speed after the engine has been warmed up. It controls the idle speed by regulating the fuel injection volume and the throttle position.

### Idle Speed Control

|                      |                                                                                                                                                                                                                                                                                                                                         |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Starting Control     | When starting the engine, this control opens the throttle valve to increase the intake air volume, which improves the startability of the engine.                                                                                                                                                                                       |
| Forecast Control     | When the system detects any one of the signals listed below, it controls the position of the throttle valve to suppress speed fluctuations.                                                                                                                                                                                             |
|                      | ·A change in the idle speed has been forecasted.                                                                                                                                                                                                                                                                                        |
|                      | ·A change occurred in the electrical load.                                                                                                                                                                                                                                                                                              |
|                      | ·The air conditioning switch has been switched.                                                                                                                                                                                                                                                                                         |
|                      | ·The shift lever has been shifted. (N → D, D → N)                                                                                                                                                                                                                                                                                       |
| Deceleration Control | This control increases the airflow volume by opening the throttle valve during deceleration, thus lowering the vacuum in the intake manifold. This decreases the volume of oil consumed through suction into the combustion chamber, prevents the engine from stalling through a sudden drop in engine speed, and improves drivability. |
| Feedback Control     | While measuring the engine speed for a certain length of time, if there is a difference between the actual speed and the target speed, this control regulates the throttle valve position in order to bring the idle speed to the target speed.                                                                                         |

### Target Speed

|                         |           | 3GR-FSE |
|-------------------------|-----------|---------|
| No-load speed           | [rpm]     | 650     |
| With an electrical load | [rpm]     | 650     |
| A/C ON                  | Low load  | 650     |
|                         | High load | 800     |