



Position of Parts in Engine Compartment (1UR-FE w/o Heated Windshield Defroster)




A31	Headlight Cleaner Motor and Pump Assembly
A32	Headlight Cleaner Control Relay
A33	Wireless Door Lock Buzzer
A34	Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
A35	Headlight Assembly RH
A36	Headlight Assembly RH
A37	Short Connector
A38	Short Connector
A41	Front Television Camera Assembly
A42	Front Wiper Deicer (Windshield Glass)
A44	Front Absorber Control Actuator RH
A45	Front Absorber Control Actuator LH
A47	Smog Ventilation Sensor
A49	Headlight Assembly LH
A50	Headlight Assembly RH
A54	Junction Connector
A55	Junction Connector
A56	Junction Connector
A57	Junction Connector
A58	Junction Connector
A60	Noise Filter (Condenser Fan)
A61	No. 1 Pressure Switch
A62	Headlight Assembly LH
A63	Headlight Assembly RH
A64	Headlight Assembly LH
A65	Headlight Assembly RH
A68	Fog Light Assembly LH
A69	Fog Light Assembly RH


Position of Parts in Engine Compartment (1UR-FE w/o Heated Windshield Defroster)




90980-10981




90980-11194




90980-12572



90980-11156




90980-11156




90980-11019




90980-10945




90980-10946




90980-12495




90980-11348




90980-11929




90980-11929




90980-11034




90980-10897




90980-10897




90980-10891



90980-10891



90980-12372



90980-12737

Position of Parts in Engine Compartment (1UR-FE w/o Heated Windshield Defroster)

