
























Position of Parts in Body <LHD>



L 1 Front No. 1 Speaker Assembly RH
L 3 Door Side Airbag Sensor RH
L 5 Front No. 2 and No. 3 Speaker Assembly RH (Front No. 3 Speaker Assembly)
L 6 Front Door Courtesy Light Assembly RH
L 7 Front Seat Memory Switch RH
L 8 Front Door Lock Assembly RH
L 9 Outer Mirror Control ECU Assembly RH
L 10 Outer Mirror Control ECU Assembly RH
L 11 Junction Connector
L 14 Outer Rear View Mirror Assembly RH
L 18 Front Power Window Regulator Motor Assembly RH
L 20 Front Power Window Regulator Switch Assembly RH
L 24 Front Door Electrical Key Oscillator RH
L 25 Front Door Handle Electrical Key Antenna RH


M 2 Front Door Lock Assembly LH
M 3 Door Side Airbag Sensor LH
M 5 Front Door Courtesy Light Assembly LH
M 6 Front Seat Memory Switch LH
M 9 Outer Mirror Control ECU Assembly LH
M 10 Outer Mirror Control ECU Assembly LH
M 12 Front No. 2 and No. 3 Speaker Assembly LH (Front No. 3 Speaker Assembly)
M 13 Front No. 1 Speaker Assembly LH
M 14 Junction Connector
M 15 Outer Rear View Mirror Assembly LH
M 18 Front Power Window Regulator Motor Assembly LH
M 21 Outer Mirror Switch Assembly
M 22 Outer Mirror Switch Assembly
M 23 Power Window Regulator Master Switch Assembly
M 24 Front Door Electrical Key Oscillator LH
M 25 Front Door Handle Electrical Key Antenna LH

Position of Parts in Body <LHD>




Position of Parts in Body <LHD>


M 15
White




M 18
Black




M 21
White




M 22
Black



M 23
White



M 24
Black



M 25
White

