















Position of Parts in Instrument Panel <LHD>

- * 2:w/o Headlight Cleaner
- * 4:A/T
- * 6:Before Aug. 2010 Production
- * 7:From Aug. 2010 Production
- * 8:Refer to the Service Bulletin
for the installation position of the parts.
- * 9:Before Aug. 2011 Production
- * 10:From Aug. 2011 Production



- J 61 Display & Navigation Module Display
- J 62 Display & Navigation Module Display
- J 63 Display & Navigation Module Display
- J 65 Radio Receiver Assembly
- J 66 Radio Receiver Assembly
- J 68 Oxygen Sensor (Bank 1 Sensor 2)
- J 69 ID Code Box
- J 70 Junction Connector
- J 71 Junction Connector
- J 73 No. 2 Interior Illumination Light Assembly RH
- J 74 Main Body ECU RH (Cowl Side J/B RH)
- J 75 Main Body ECU RH (Cowl Side J/B RH)
- J 76 Network Gateway ECU
- J 79 Lower No. 2 Instrument Panel Airbag Assembly
- J 80 Junction Connector
- J 86 Headlight Leveling Switch
- J 87 No. 1 Pattern Select Switch Assembly
- J 87 No. 1 Pattern Select Switch Assembly
- J 87 No. 1 Pattern Select Switch Assembly
- J 88 Parking Brake Switch Assembly
- J 89 Stop Light Control Relay
- J 90 Front Wiper Deicer Switch

Position of Parts in Instrument Panel <LHD>



Position of Parts in Instrument Panel <LHD>

