














Position of Parts in Engine Compartment (LHD 8AR-FTS)

- * 3: Cooling Fan Motor 240W Type
- * 4: Cooling Fan Motor 300W Type
- * 5: Before Oct. 2016 Production
- * 6: From Oct. 2016 Production
- * 7: w/ Stop & Start System
- * 8: w/o Stop & Start System
- * 9: Before May. 2017 Production
- * 10: From May. 2017 Production



A68	No. 1 Wiring Harness Condenser Assembly
A69	No. 1 Junction Connector
A71	No. 2 Junction Connector
A73	No. 1 Ground Junction Connector
A79	Battery
A81	Front Wiper Deicer (Windshield Glass)
A85	Electric Water Pump Assembly
A86	Vacuum Warning Switch Assembly
A87	No. 1 Cooling Fan ECU
A91	ECM
A92	Battery Current Sensor Assembly
A95	Brake Booster Pressure Sensor (Vacuum Sensor Assembly)
A97	No. 1 Cooling Fan ECU
A99	No. 15 Junction Connector
A100	Brake Actuator Assembly
A104	Battery Current Sensor Assembly
A105	Brake Actuator Assembly

Position of Parts in Engine Compartment (LHD 8AR-FTS)



Position of Parts in Engine Compartment (LHD 8AR-FTS)

