



Position of Parts in Instrument Panel (LHD)



K1	Main Body ECU
K2	Main Body ECU
K3	Combination Meter Assembly
K4	Combination Meter Assembly
K5	Certification ECU
K6	Certification ECU
K9	DLC3
K10	A/C Amplifier Assembly
K11	A/C Amplifier Assembly
K13	Quick Heater Assembly
K14	Quick Heater Assembly
K15	Steering Actuator Assembly
K16	Front Steering Control ECU
K17	Front Steering Control ECU
K18	Front Steering Control ECU
K19	Multiplex Tilt & Telescopic ECU
K20	Tilt Steering Gear with Motor Assembly
K21	Tilt Steering Gear with Motor Assembly
K22	Tilt & Telescopic Switch
K23	Headlight Dimmer Switch Assembly
K24	Windshield Wiper Switch Assembly
K25	Windshield Wiper Switch Assembly
K26	Spiral Cable with Sensor Sub-Assembly
K27	Spiral Cable with Sensor Sub-Assembly
K28	Steering Lock Actuator Assembly
K29	Steering Sensor
K30	Steering Sensor
K140	Spiral Cable with Sensor Sub-Assembly
K166	DLC3


Position of Parts in Instrument Panel (LHD)

K1
White




90980-12908

K2
White




90980-12909

K3
Black




90980-12557

K4
Black




90980-12767

K5
Black




90980-12912

K6
Black




90980-12A42

K9
White




90980-11665

K10
White




90980-12528

K11
White




90980-12529


Position of Parts in Instrument Panel (LHD)




90980-10903




90980-10903




90980-11547




82824-30570




82824-30580




90980-12368




90980-12976




90980-10797




90980-10797




90980-12695




90980-12554




90980-12460




90980-12358




90980-12370




90980-10795




90980-12092



90980-12551



90980-12368



90980-12A94

