










Position of Parts in Instrument Panel (LHD)




K100	No. 2 Oxygen Sensor (Bank 2 Sensor 2)
K101	Oxygen Sensor (Bank 1 Sensor 2)
K102	Option Connector (Remote Engine Starter)
K104	Blind Spot Monitor Main Switch (Warning Canceling Switch Assembly)
K105	No. 6 Junction Connector
K106	No. 1 CAN Junction Terminal
K107	No. 2 CAN Junction Terminal
K109	No. 1 CAN Junction Connector
K110	No. 2 CAN Junction Connector
K111	No. 3 CAN Junction Connector
K113	No. 5 CAN Junction Connector
K115	No. 7 CAN Junction Connector
K117	Radio Receiver Assembly
K118	No. 1 Stereo Jack Adapter Assembly
K119	Radio Receiver Assembly
K120	Telematics Transceiver
K121	Radio Receiver Assembly
K122	Multi-Display Assembly
K123	Radio Receiver Assembly
K124	Combination Meter Assembly
K125	Multi-Display Assembly
K126	Radio Receiver Assembly
K127	Telematics Transceiver
K128	Antenna Cord Sub-Assembly
K130	No. 3 Antenna Cord Sub-Assembly
K131	Radio Receiver Assembly
K132	Short Connector
K133	Short Connector
K134	Front Foot Light LH (No. 1 Interior Illumination Light Assembly LH)
K138	Engine Stop & Start Solenoid Filter
K139	Engine Stop and Start ECU
K152	No. 12 CAN Junction Connector
K158	Multi-Display Assembly
K169	No. 16 CAN Junction Connector

Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)

K111
Black




90980-12372

K113
Black




90980-12372

K115
Black




90980-12372

K117
Gray




90980-12A52

K118
Gray




90980-12A52

K119
White




90980-12602

K120
White




90980-12602

K121
Blue




90980-12957

K122
Blue



90980-12593

K123
Green




90980-12A73

K124
Blue




90980-12593

K125
Blue




90980-12593

K126
Blue




90980-50022

K127
Blue




90980-50022

K128
Blue




90980-50036

K130
White




90980-50026


Position of Parts in Instrument Panel (LHD)




90980-12A52




82824-53060




82824-53070




90980-11148





90980-12558




82824-12510



90980-12372



90980-12C80



90980-12372

