


F RELAY LOCATIONS


② : Engine Room R/B No.2

○ : Engine Room J/B No.2

Engine Compartment Left (See Page 20)

(Gasoline)





F RELAY LOCATIONS

② : Engine Room R/B No.2

○ : Engine Room J/B No.2

Engine Compartment Left (See Page 20)

(Diesel)

