




- R 1 Vanity Lamp SW (LH)
- R 2 Vanity Lamp (LH)
- R 3 Vanity Lamp SW (RH)
- R 4 Vanity Lamp (RH)
- R 5 Overhead J/B
- R 6 Sliding Roof Control ECU
- R 7 Rain Sensor
- R 8 Room Lamp
- R 9 Inner Rear View Mirror

- S 1 Ultrasonic Sensor (Rear Corner LH)
- S 2 Ultrasonic Sensor (Rear Corner RH)
- S 3 Ultrasonic Sensor (Rear Center LH)
- S 4 Ultrasonic Sensor (Rear Center RH)

- X 1 Speed Sensor (Rear RH)

- Y 1 Speed Sensor (Rear LH)
- Y 2 Height Control Sensor (Rear)

- g 1 Outer Mirror Control ECU (RH) , Outer Rear View Mirror (RH)

- h 1 Outer Mirror Control ECU (LH) , Outer Rear View Mirror (LH)

- n 1 Door Outside Handle (Front RH)
- n 2 Electrical Key Oscillator (Front Door RH)

- o 1 Door Outside Handle (Front LH)
- o 2 Electrical Key Oscillator (Front Door LH)

- t 1 Stereo Component Amplifier

Position of Parts in Body <LHD>

