



























L 1 Speaker (Woofer Front Door RH)
 L 2 Speaker (Midrange Front Door RH)
 L 4 Power Window Regulator Motor (Front RH)
 L 5 Tweeter (Front Door RH)
 L 6 Courtesy Lamp (Front Door RH)
 L 7 Seat Memory SW (RH)
 L 8 Door Lock Assembly (Front RH)
 L 10 Outer Mirror Control ECU (RH)
 L 11 Junction Connector
 L 12 Outer Rear View Mirror (RH)
 L 14 Outer Rear View Mirror (RH)
 L 15 Outer Mirror SW
 L 16 Outer Mirror SW
 L 17 Power Window Master SW

M 2 Door Lock Assembly (Front LH)
 M 3 Power Window Regulator Motor (Front LH)
 M 4 Speaker (Midrange Front Door LH)
 M 5 Courtesy Lamp (Front Door LH)
 M 6 Seat Memory SW (LH)
 M 10 Outer Mirror Control ECU (LH)
 M 11 Outer Rear View Mirror (LH)
 M 12 Tweeter (Front Door LH)
 M 13 Speaker (Woofer Front Door LH)
 M 14 Junction Connector
 M 15 Outer Rear View Mirror (LH)
 M 16 Power Window SW (Front LH)
 M 17 Door Lock Control SW


N 1 Power Window SW (Rear RH)
 N 2 Speaker (Midrange Rear Door RH)
 N 3 Speaker (Woofer Rear Door RH)
 N 4 Speaker (Midrange Rear Door RH)
 N 5 Tweeter (Rear Door RH)
 N 6 Tweeter (Rear Door RH)
 N 7 Power Window Regulator Motor (Rear RH)
 N 8 Door Lock Assembly (Rear RH)

O 1 Power Window SW (Rear LH)
 O 2 Speaker (Midrange Rear Door LH)
 O 3 Speaker (Woofer Rear Door LH)
 O 4 Speaker (Midrange Rear Door LH)
 O 5 Tweeter (Rear Door LH)
 O 6 Tweeter (Rear Door LH)
 O 7 Power Window Regulator Motor (Rear LH)
 O 8 Door Lock Assembly (Rear LH)

Position of Parts in Body <RHD>



Position of Parts in Body <RHD>



(w/ Seat Position Memory)

