


















- J 61 Radio Receiver Assembly
- J 62 Radio Receiver Assembly
- J 63 Radio Receiver Assembly
- J 65 Radio Receiver Assembly
- J 66 Radio Receiver Assembly
- J 67 Antenna Amplifier
- J 68 Heated Oxygen Sensor (Bank 1 Sensor 2)
- J 69 ID Code Box
- J 70 Junction Connector
- J 71 Junction Connector
- J 73 Register Illumination (RH)
- J 74 Body ECU (Cowl Side J/B RH)
- J 75 Body ECU (Cowl Side J/B RH)
- J 76 Gateway ECU
- J 77 Skid Control ECU
- J 78 Skid Control ECU
- J 79 Airbag Squib (Front Passenger's Side Knee Airbag)
- J 80 Junction Connector
- J 81 Junction Connector
- J 82 Junction Connector
- J 84 Junction Connector
- J 87 ETCS Snow SW
- J 88 Parking Brake SW
- J 89 Headlamp Leveling SW
- J 90 Front Wiper Deicer SW
- J 91 Airbag Cut Off SW
- J 92 Television Camera Controller
- J 93 Television Camera Controller
- J 94 Junction Connector
- J 95 Power Heater SW
- J 96 Junction Connector
- J 97 Junction Connector
- J 98 Skid Control ECU

Position of Parts in Instrument Panel <RHD>



Position of Parts in Instrument Panel <RHD>

