


■ AVC-LAN**1. Layout of Main Component**

2. Diagnosis

If a malfunction occurs on the AVC-LAN communication line, the multi display (models with multi display) or audio head unit (models without multi display) stores the DTCs (Diagnostic Trouble Codes) in its memory.

- The DTCs of models with multi display can be read on the diagnosis menu on the multi display.
- The DTCs of models without multi display can be read on the LCD of the audio head unit. For details, see the LEXUS IS250 Repair Manual (Pub. No. RM0150E).