

SMART ENTRY & START SYSTEM

■ DESCRIPTION

The smart entry & start system not only has a wireless door lock remote control function and engine immobilizer function, but by carrying the key the following functions (entry function and push button start function) are also possible, without having to use a key or transmitter button. It is an extremely convenient system.


- Door unlock/lock (Entry Unlock/Entry Lock Functions)
- The engine can be started by simply pressing the engine switch while depressing the brake pedal (Start Function) (A/T models)
- The engine can be started by simply pressing the engine switch while depressing the clutch pedal (Start Function) (M/T models)
- The trunk can be opened (Trunk Open Function)
- Wireless door lock control function.

This system is standard equipment on the all models.

Entry Unlock/Lock Functions



Start Function



A/T models

M/T models

Trunk Open Function

