


■ ACTUATION AREA

The special functions of the smart entry & start system only work when the key is in the actuation area formed by the six oscillators.

- The front and rear room oscillator forms the actuation area of the push button start function.
- Front door oscillators and outer trunk oscillators form the actuation area of the entry function.



0140BE227C