


SRS AIRBAG SYSTEM

■ DESCRIPTION

The SRS (Supplemental Restraint System) airbag system has the following equipment:

Item		Equipment
Frontal Collision	Driver and Front Passenger	Standard
	Driver Knee and Front Passenger Knee	Standard
	Seat Belt Pretensioner	Standard
Side/Rear Side Collision	Side	Standard
	Curtain Shield	Standard
	Seat Belt Pretensioner	Standard



BE

- The SRS driver and front passenger airbags are used to help to reduce the shocks to the head and chest of the driver or front passenger in the event of a frontal impact collision as supplements to the seat belts.
- The SRS knee airbags are used to help to reduce the shocks to the knees of the driver and front passenger in the event of a frontal impact collision as supplements to the seat belts.
- The SRS side airbags are used to help to reduce the shocks to the chest of the driver or front passenger in the event of a side impact collision.
- The SRS curtain shield airbags is used to help to reduce the shocks to the head of the driver, front passenger, or rear outer passenger in the event of a side or rear side impact collision.