


## REAR WINDOW DEFOGGER SYSTEM

### DESCRIPTION

The rear window defogger system uses the heater wire on the rear window glass to defog the rear window glass.


- This system is standard equipment on all models.
- The rear window defogger system operates at the same time as the heater function of the outside rear view mirror.
- This system is activated when the power source is turned IG-ON, and rear window defogger switch is pushed. This switch is provided with a timer function to keep the defogger and mirror heater ON for approx. 15 minutes.

### System Diagram



Models without Multi Display

0140BE107C



Models with Multi Display

0140BE108C