


FUEL LID OPENER

DESCRIPTION


An emergency opener has been provided in case the system does not operate due to a discharged battery or other malfunctions.

► System Diagram ◀




0140BE114C

LAYOUT OF MAIN COMPONENT



BE



0140BE116Z