


Position of Parts in Body (LHD)























* 2:Before Sep. 2018 Production

* 3:From Sep. 2018 Production



V1	Door Outside Handle Sub-Assembly RH
V2	Door Outside Handle Sub-Assembly RH
V3	Door Outside Handle Sub-Assembly RH
V4	Door Outside Handle Sub-Assembly RH
W1	Door Outside Handle Sub-Assembly LH
W2	Door Outside Handle Sub-Assembly LH
W3	Door Outside Handle Sub-Assembly LH
W4	Door Outside Handle Sub-Assembly LH
Z1	Visor Assembly LH
Z2	Map Light Sub-Assembly
Z3	Map Light Sub-Assembly
Z4	Visor Assembly RH
Z5	Telephone Microphone Assembly
Z6	Front Active Noise Control Microphone LH
Z7	Front Active Noise Control Microphone RH
Z8	Rain Sensor
a1	Forward Recognition Camera
a2	Inner Rear View Mirror Assembly
a3	Forward Recognition with Heater Hood Sub-Assembly
a4	Rain Sensor
b1	No. 3 Indoor Electrical Key Antenna Assembly
b2	Canister Pump Module
b3	Rear Steering Control ECU
b4	Battery State Sensor Assembly
b5	Sub-Battery with Control Assembly
b7	Sub-Battery with Control Assembly
b8	Fusible Link Block Assembly No. 2
b9	Fusible Link Block Assembly No. 2
b10	No. 18 CAN Junction Connector
b11	No. 3 Semiconductor Power Integration ECU
b12	Battery State Sensor Assembly

Position of Parts in Body (LHD)



Position of Parts in Body (LHD)

