


Position of Parts in Engine Compartment (RHD)

* 1: Before Sep. 2018 Production
* 2: From Sep. 2018 Production



G30 Hybrid Vehicle Transmission Assembly
G31 Hybrid Vehicle Transmission Assembly
G32 Hybrid Vehicle Transmission (Transmission Wire)
G33 Transmission Revolution Sensor
G34 Engine Coolant Temperature Sensor
G35 Fuel Pump Assembly
G36 Engine Oil Level Sensor
G37 Oil Pump with Motor Assembly
G39 Crank Position Sensor
G40 EGR Valve Assembly
G41 Shift Control Actuator Assembly
G46 Shift Control Actuator Assembly
G78 No. 3 Junction Connector
G79 Engine Coolant Temperature Sensor

Position of Parts in Engine Compartment (RHD)

