



Position of Parts in Instrument Panel (LHD)




* 1: Refer to the Service Bulletin for the installation position of the parts.


P60	Glove Compartment Door Assembly
P61	Pre-Collision City Buzzer
P62	Driving Support ECU Assembly
P63	No. 3 Combination Switch Assembly
P64	Hybrid Vehicle Control ECU Assembly
P65	Hybrid Vehicle Control ECU Assembly
P66	Certification ECU
P67	Luggage Door Opening Cancel Switch Assembly
P68	Clock Assembly
P69	Remote Operation Controller Assembly
P70	Front Steering Control ECU
P71	Front Steering Control ECU
P72	Front Steering Control ECU
P73	Integration Control & Panel Assembly
P74	Shift Control ECU
P75	Shift Control ECU
P76	Transmission Floor Shift Assembly
P77	No. 1 Stereo Jack Adapter Assembly
P78	No. 4 Combination Switch Assembly
P79	Option Connector
P80	Meter Mirror Sub-Assembly
P81	Ion Generator Sub-Assembly
P83	Double Lock Door Control Relay Assembly
P84	Integration Control & Panel Assembly
P85	Combination Switch Assembly
P86	Switch & Volume Assembly
P87	Center Instrument Panel Register Assembly
P88	Telltale Light Assembly
P89	No. 4 Junction Connector
P90	No. 5 Junction Connector
P91	No. 6 Junction Connector
P92	No. 7 Junction Connector
P93	No. 8 Junction Connector
P94	No. 9 Junction Connector
P98	Radio Receiver Assembly
P99	Radio Receiver Assembly




90980-12366




90980-10860




90980-12422




90980-12412




90980-12429




90980-12431




90980-12B78




90980-10825




90980-12558




90980-12361




82824-30570




90980-12368




82824-30580




90980-12910




90980-12562



90980-12561


















90980-12553



90980-12910

Position of Parts in Instrument Panel (LHD)



Position of Parts in Instrument Panel (LHD)

