



# Position of Parts in Instrument Panel (LHD)



|      |                                           |
|------|-------------------------------------------|
| P100 | Radio Receiver Assembly                   |
| P101 | Multi-Display                             |
| P102 | No. 1 Stereo Jack Adapter Assembly        |
| P107 | No. 1 CAN Junction Connector              |
| P108 | No. 2 CAN Junction Connector              |
| P109 | No. 3 CAN Junction Connector              |
| P110 | No. 3 CAN Junction Connector              |
| P111 | No. 3 CAN Junction Connector              |
| P112 | No. 3 CAN Junction Connector              |
| P113 | No. 3 CAN Junction Connector              |
| P114 | No. 3 CAN Junction Connector              |
| P116 | No. 4 CAN Junction Connector              |
| P117 | No. 5 CAN Junction Connector              |
| P118 | No. 6 CAN Junction Connector              |
| P119 | No. 6 CAN Junction Connector              |
| P120 | No. 6 CAN Junction Connector              |
| P121 | No. 6 CAN Junction Connector              |
| P122 | No. 6 CAN Junction Connector              |
| P123 | No. 6 CAN Junction Connector              |
| P125 | No. 8 CAN Junction Connector              |
| P126 | No. 8 CAN Junction Connector              |
| P127 | No. 8 CAN Junction Connector              |
| P128 | No. 8 CAN Junction Connector              |
| P130 | No. 8 CAN Junction Connector              |
| P132 | No. 9 CAN Junction Connector              |
| P133 | No. 2 Semiconductor Power Integration ECU |
| P134 | Telephone Transceiver Assembly            |
| P135 | Mayday Battery                            |
| P136 | Telephone Transceiver Assembly            |
| P137 | Navigation ECU                            |

## Position of Parts in Instrument Panel (LHD)



## Position of Parts in Instrument Panel (LHD)

