















Position of Parts in Instrument Panel (RHD)



* 1: Refer to the Service Bulletin for the installation position of the parts.


P30	Airbag Cut Off Switch Cylinder Sub-Assembly
P31	Lower No. 1 Instrument Panel Airbag Assembly
P32	Lower No. 2 Instrument Panel Airbag Assembly
P35	Yaw Rate Sensor
P36	Electric Parking Brake Switch Assembly
P37	No. 1 Indoor Electrical Key Antenna Assembly
P39	Shift Position Indicator
P40	Pedestrian Detection ECU Assembly
P41	Pedestrian Detection ECU Assembly
P42	Multi-Display
P43	Radio Receiver Assembly
P45	Radio Receiver Assembly
P46	Radio Receiver Assembly
P47	Navigation ECU
P51	ID Code Box
P52	No. 2 Combination Switch Assembly
P53	Quick Heater Assembly
P54	Quick Heater Assembly
P55	No. 1 Power Outlet Socket Assembly
P56	Air Conditioning Amplifier Assembly
P57	Air Conditioning Amplifier Assembly
P58	Air Conditioning Amplifier Assembly
P59	Network Gateway ECU
P60	Glove Compartment Door Assembly
P61	Pre-Collision City Buzzer
P62	Driving Support ECU Assembly
P63	No. 3 Combination Switch Assembly
P64	Hybrid Vehicle Control ECU Assembly
P65	Hybrid Vehicle Control ECU Assembly
P66	Certification ECU
P67	Luggage Door Opening Cancel Switch Assembly
P68	Clock Assembly
P69	Remote Operation Controller Assembly

Position of Parts in Instrument Panel (RHD)




Position of Parts in Instrument Panel (RHD)

P47
Black




90980-12912

P51
White




90980-12366

P52
Gray




90980-12368

P53
White




90980-10903

P54
Blue




90980-10903

P55
White




90980-12498

P56
White




82824-52380

P57
White




90980-12761

P58
White




90980-12760

P59
Black




90980-12912

P60
White




90980-12366

P61
Blue




90980-10860


Position of Parts in Instrument Panel (RHD)




90980-12422




90980-12412




90980-12429




90980-12431




90980-12B78



90980-10825



90980-12558



90980-12361