


Position of Parts in Engine Compartment <LHD 1UR-FSE From Sep. 2012 Production>

* 3: Before Sep. 2015 Production
* 4: From Sep. 2015 Production



F 1 Starter

H 1 Injector Driver (No. 1)
H 2 Injector Driver (No. 1)
H 3 Injector Driver (No. 2)
H 4 Injector Driver (No. 2)
H 5 Fuel Injector (for Direct Injection No. 8)
H 6 Fuel Injector (for Direct Injection No. 6)
H 7 Knock Sensor (Bank 2 Sensor 2)
H 8 Fuel Injector (for Direct Injection No. 4)
H 9 Fuel Injector (for Direct Injection No. 2)
H 10 Knock Sensor (Bank 2 Sensor 1)
H 11 Fuel Injector (for Direct Injection No. 7)
H 12 Knock Sensor (Bank 1 Sensor 2)
H 13 Fuel Injector (for Direct Injection No. 5)
H 14 Knock Sensor (Bank 1 Sensor 1)
H 15 Fuel Injector (for Direct Injection No. 3)
H 16 Fuel Injector (for Direct Injection No. 1)
H 17 Fuel Pressure Sensor
H 18 Fuel Injector (for Direct Injection No. 8)
H 19 Fuel Injector (for Direct Injection No. 6)
H 20 Fuel Injector (for Direct Injection No. 4)
H 21 Fuel Injector (for Direct Injection No. 2)
H 22 Fuel Injector (for Direct Injection No. 7)
H 23 Fuel Injector (for Direct Injection No. 5)
H 24 Fuel Injector (for Direct Injection No. 3)
H 25 Fuel Injector (for Direct Injection No. 1)

I 5 Fuel Injector (for Port Injection No. 2)
I 6 Fuel Injector (for Port Injection No. 4)
I 7 Fuel Injector (for Port Injection No. 6)
I 8 Fuel Injector (for Port Injection No. 8)


J 5 Fuel Injector (for Port Injection No. 1)
J 6 Fuel Injector (for Port Injection No. 3)
J 7 Fuel Injector (for Port Injection No. 5)
J 8 Fuel Injector (for Port Injection No. 7)

x 1 VGRS Actuator
x 2 VGRS Actuator

z 3 Fan Control ECU , Cooling Fan Motor (Main)
z 4 Fan Control ECU , Cooling Fan Motor (Sub)
z 22 Crankshaft Position Sensor


Position of Parts in Engine Compartment <LHD 1UR-FSE From Sep. 2012 Production>

F 1



(RHD 4WD, LHD From Sep. 2008 Production)


F 1



(RHD 2WD, LHD Before Sep. 2008 Production)


H 1

Gray




H 2

Black




H 3

Gray



H 4

Black



H 5

Gray




H 6

Gray



H 7

Black



H 8

Gray




H 9

Gray



H 10

Black




H 11

Black



H 12

Gray




H 13

Black



H 14

Gray



H 15

Black




H 16

Black




H 17

Dark Gray




H 18

Gray




H 19

Gray




H 20

Gray




H 21

Gray




H 22

Black




H 23

Black




H 24

Black




H 25

Black




I 5

Black



I 6

Black



Position of Parts in Engine Compartment <LHD 1UR-FSE From Sep. 2012 Production>

