


F RELAY LOCATIONS




: Fusible Link Block Assembly No.2

Luggage Room Left (See Page 25)

(Before Nov. 2009 Production)



(Before Nov. 2009 Production)




F RELAY LOCATIONS

 : Fusible Link Block Assembly No.2

Luggage Room Left (See Page 25, 26)

(From Nov. 2009 Production)

- * 1:40A LUG-J/B BATT (for High Current)
- * 2:40A LH-J/B BATT (for High Current)
- * 3:80A EPS (for High Current)
- * 4:160A E/G R/B BATT (for High Current)
- * 5:180A DC/DC (for High Current)
- * 6:30A RR A/C (for High Current)
- * 7:80A LH-J/B DC/DC (for High Current)
- * 8:80A LUG-J/B DC/DC (for High Current)
- * 9:160A E/G R/B DC/DC (for High Current)
- * 10:40A NOISE FILTER (for High Current)



(From Nov. 2009 Production)

