




R	2	Front Pre-Crash Seat Belt Motor RH
R	3	Front Pretensioner RH
R	6	Front Door Courtesy Light Switch Assembly RH
R	7	Side Airbag Sensor Assembly RH
R	9	Front Tension Reducer RH
R	10	Sub Fuel Sender Gauge Assembly
R	11	Rear Airbag Sensor RH
R	12	Rear Door Courtesy Light Switch Assembly RH
R	16	Disc Player Controller
R	17	Curtain Shield Airbag Assembly RH
R	18	Rear Header Speaker Assembly RH
R	19	Television Display Assembly
R	20	Floor Stereo Component Speaker Assembly
R	21	No.2 Clearance Warning Buzzer
R	22	Rear Pretensioner RH
R	25	Object Recognition ECU
R	26	Rear Acceleration Sensor Assembly
R	30	Multi-Display Selector
R	31	Multi-Display Selector
R	32	Multi-Display Selector
R	33	Multi-Display Selector
R	34	Stereo Component Amplifier Assembly
R	35	Stereo Component Amplifier Assembly
R	36	Stereo Component Amplifier Assembly
R	37	Door Control Receiver
R	38	Stereo Component Amplifier Assembly
R	39	Stereo Component Amplifier Assembly

Position of Parts in Body <RHD Before Nov. 2009 Production>

